

Serial Number:

The logo consists of the word "Powertek" in a white, bold, sans-serif font, centered within a solid blue rectangular background.

**ROGOWSKI CURRENT WAVEFORM TRANSDUCERS**

**INSTRUCTIONS FOR USE**  
**CWT Ultra Mini**

**For Sales and Support**

Powertek UK 19 Cornwallis Road Bilton, Rugby.  
CV22 7HL UK  
Tel: 01788 519911 Fax: 0870 0940135  
Int'l Fax: +1 973-273-5893  
Int'l Tel: +44 1788 519911 Int'l Fax: +44 870 0940135  
Email: [info@powertekuk.com](mailto:info@powertekuk.com)

Powertek LLC . 11 Glenwood Road . Rocky Point  
NY 11778 . USA Tel: +1 631 744 0294  
US Fax: +1 877 570 3441  
Int'l Fax: +1 973-273-5893  
North America support and sales inquiries:  
[usainfo@powertekuk.com](mailto:usainfo@powertekuk.com)

## INTRODUCTION

PEM's Rogowski Current Waveform Transducers combine high bandwidth, safety, and the minimum disruption to the circuit under test. These instructions should be followed whenever the unit is used. They are intended to help you obtain the best and safest performance from the transducer.

## SPECIFICATION

### ACCURACY (5 to 100% full scale)

Within the limits of bandwidth, Peak di/dt and low frequency noise that are specified on the relevant CWT specification sheet.

Calibration:	Normally $\pm 0.2\%$ (traceable to UKAS) with the conductor central in the Rogowski loop. See the calibration certificate for more details.
Positional accuracy:	$\pm 2\%$ typ. variation of accuracy with conductor position in the loop (see 'Obtaining The Best Measurement')
Linearity:	$\pm 0.05\%$ typ.

### POWER SUPPLY

The CWT can be powered by both battery **and** an external DC voltage. With the external DC supply present the batteries are inoperative.

Battery type:	4 (four) 1.5V AA alkali
Battery life:	30 hrs typ.
DC socket type:	2.1 or 2.5mm jack socket – polarity indicated on front of CWT
DC voltage:	12V DC ( $\pm 10\%$ )
DC quiescent supply current:	70mA @ 12V DC


### OUTPUT

Maximum output voltage:	$\pm 6V$ (corresponding to $\pm$ Peak Current Rating of CWT)
Output cable:	0.5m BNC to BNC 50 $\Omega$ cable
Minimum output loading:	$\geq 100k\Omega$ (for rated accuracy – recommend DC1M $\Omega$ on scope) = 50 $\Omega$ (for driving long cables > 10m) NB. A load of 50 $\Omega$ will reduce the CWT sensitivity by half it's normal value. It will also reduce the peak output to $\pm 2V$

### OPERATING TEMPERATURE RANGES

Rogowski coil and cable	-10°C to 70°C
Integrator electronics	0 to 40°C

## CWT Ultra Mini – ROGOWSKI CURRENT TRANSDUCER



1. Rogowski coil (loop)
2. 'Free end' of the Rogowski coil
3. Ferrule (the connecting mechanism for closing the Rogowski coil).
4. Cable connecting the Rogowski coil to the integrator electronics
5. Socket for external DC supply
6. LED status indicator for external DC supply
7. Enclosure for the integrator electronics
8. Output BNC socket
9. 4 x AA batteries
10. LED indicator  
- GREEN - CWT is ON  
- RED - low battery
11. Push button ON / OFF switch






## SAFETY AND PRE-USE CHECKS

Throughout this instruction sheet there are a number of warnings which must be observed to ensure safe operation of this unit. These warnings are identified by the following symbol:




PEM accepts no responsibility for any accidents or damage resulting from careless use, or non-observance of these instructions.

### THE ULTRA MINIATURE ROGOWSKI COIL

-  The integrity of the insulation around the Rogowski coil itself should be VISUALLY INSPECTED before use, and the unit should NOT BE USED if there are signs of damage.
-  When bending the flexible coil around a conductor, avoid tight bends and sharp edges that could damage the coil.
-  The voltage rating (safe PEAK working voltage) is clearly labelled on the cable adjacent to the coil. For the CWT Ultra Miniature this is 1.2kV peak. Never use at voltages greater than this value.
-  Voltage ratings are only valid if the 'free-end' of the coil is fully inserted into the socket, and remains fully inserted during use. The coil has a friction fit, the coil is fully inserted when the user feels they can ease the coil free end into the ferrule no further.
-  The voltage ratings are appropriate for intermittent use of the CWT as a test instrument and not for continuous use in a permanent installation.  
The ratings are derived from the following standard test: Coils rated for 1.2kV peak are flash tested for one minute at 3.0kVrms using a 50Hz sine-wave voltage.  
For permanent installation the coil should be situated such that corona, which will eventually damage the coil insulation, cannot occur. For information regarding permanent installation of PEM's Rogowski coils on high voltage equipment please consult PEM.

### THE INTEGRATOR


-  The CWT must only be used with oscilloscopes or monitoring equipment which have their BNC INPUTS PROPERLY GROUNDED.

## HANDLING INSTRUCTIONS

To achieve such an extremely thin Rogowski coil the CWT Ultra Mini is necessarily delicate.




Every effort has been made to ensure that the CWT Ultra Mini is as robust as possible. To prolong the life of the coil please observe the following handling instructions.

The free end of the coil is unclipped in the direction shown.



When clipping or unclipping the coil, hold the ferrule as shown



-  Never force the free end of the coil into the ferrule. This may damage the coil insulation.
-  Take care not to put any force onto the cable attached to the coil. This may damage the coil.
-  When not in use return the CWT ultra mini coil to its protective cover.

## OUTPUT CABLES

A 0.5m BNC-BNC output cable is supplied with the unit but a longer cable can be used. The cable should be a 50 ohm singly screened co-axial cable. Although at present this has not been included in the immunity tests and may decrease RF noise immunity, PEM does not consider the use of extension cables to be problematic from the noise viewpoint.

## WARRANTY

The coil is guaranteed to be free from defects due to materials and workmanship for 12 months and the integrator for 24 months from the date of despatch from Power Electronic Measurements Ltd. In the event of a defect or incorrect operation of the unit where the transducer has not been misused the CWT should be returned to PEM with all freight charges to be paid by the customer. Correction shall be in the form of repair or replacement.

## RETURNING CWTs FOR RECALIBRATION OR REPAIR

If it is necessary to return the CWT to PEM for repair whether or not under warranty please contact PEM in advance for shipping instructions (see last below for contact details). To facilitate customs clearance it is important to follow the correct procedure otherwise import tax will be charged. PEM will not accept units sent for recalibration or repair if the relevant procedure is not followed.

The logo for Powertek, featuring the word "Powertek" in white, bold, sans-serif font centered within a solid blue rectangular background.

### **For Sales and Support**

Powertek UK 19 Cornwallis Road Bilton, Rugby.  
CV22 7HL UK

New Tel: 01788 519911 Fax: 0870 0940135

Int'l Fax: +1 973-273-5893

Int'l Tel: +44 1788 519911 Int'l Fax: +44 870 0940135

Email: [info@powertekuk.com](mailto:info@powertekuk.com)

Powertek LLC . 11 Glenwood Road . Rocky Point

NY 11778 . USA Tel: +1 631 744 0294

US Fax: +1 877 570 3441

Int'l Fax: +1 973-273-5893

North America support and sales inquiries:

[usainfo@powertekuk.com](mailto:usainfo@powertekuk.com)